



# F&J SPECIALTY PRODUCTS, INC.

*The Nucleus of Quality Air Monitoring Programs*

## ECONOAIR PREMIUM L-12PTR

### NOTABLE FEATURES:

- Compact, Rugged and Quiet
- No tools required to change flow rates
- Flow setting is saved in memory for next day quick start
- Battery pack rechargeable while attached or separately
- Stainless steel belt clip with built-in tripod connector
- One-hour rechargeable batteries and extended run triple packs
- High impact steel fiber filled Lexan case, antistatic and RFI shielded
- "Auto-restart" within one minute of a flow fault
- Flows up to 12 LPM
- High backpressure capable for 25mm 0.45 $\mu$  asbestos filters
- Built in washable stainless steel 100 micron filter for economy of use
- NiMH batteries; 6.45 Ah
- Displays: Total Accumulated Volume, Elapsed Time, Battery Life, Countdown Clock and Current Flowrate
- Timing routine activated sampling
- Correction of flow rates and volumes to a Reference Temperature and Pressure
- One year warranty
- Premium models are capable of Data Logging. PC Software and for download of data requires optional PC link cable
- The PC link with Windows 10 and Windows 11 operating system using the RS232
- Delayed start time with auto shut off feature is available upon request



### GENERAL DESCRIPTION:

The ECONOAIR Premium L-12PTR is a low-cost high-performance personal air sampling pump. It is a simple model designed for sampling of asbestos, lead and other airborne contaminants. The rugged compact design features a rechargeable NiMH battery with available one-hour recharger. The L-12PTR can be programmed for timing routine activated sampling.

The sealed pump case protects the internal components from dust, fibers and moisture. Simplicity of its operation features establishment of flows at 4, 8 and 10 LPM's, maintained within 5% for full constant flow compensation using 37 and 25 mm cassettes interchangeable. This insures accurate sample volumes based on the run time. The ECONOAIR Premium L-12PTR is capable of delivering up to 12 LPM for periods exceeding 8 hours. Bright LCD's indicate pump ON, Flow Fault or a Low Battery.

The ECONOAIR Premium features a two line display that displays flowrate, accumulated volume, elapsed time, battery life and a countdown timer.

The operator can select to report flow rates and volumes to ambient conditions or to a Reference Temperature and Pressure.

Rev.: 20 February 2025



Press SET button and hold while using the Arrow keys to adjust flow

**ON/OFF Button:** Press to turn ON, pump will begin running at previous set flow rate. Press and hold for 3 seconds to turn OFF.

**Total Flow Range:** 3-12 LPM

**Power:** Rechargeable NiMH Batteries; 4.8Vm 6.45 Ah

**Operating Temperature Range:** 32° to 122°F (0° to 50°C)

**Case:** Polycarbonate steel fiber filled; RFI-shielded and antistatic

**Size:** 6.5"H × 4"W × 2"D (16,5 × 10.2 × 5 cm)

**Displayed Information:** Current Flowrate Elapsed Time Battery Life  
Accumulated Volume Countdown Timer

## PERFORMANCE PROFILE

**Accuracy:** ± 5% of the flow set point

### Constant Flow Range:

12.0 LPM up to 4.5" water backpressure  
10.0 LPM up to 10" water backpressure  
8.00 LPM up to 15" water backpressure  
6.00 LPM up to 30" water backpressure  
4.00 LPM up to 36" water backpressure  
3.00 LPM up to 40" water backpressure

### Pump Run Times with Sampling Filters

	5"	10"	15"	20"	25"
12 LPM	12.6 hr				
10 LPM	16.1 hr	12.9 hr			
8 LPM	24.3 hr	18.3 hr	14.1 hr	12.1 hr	
6 LPM	34.0 hr	25.0 hr	19.0 hr	15.4 hr	13.7 hr
5 LPM	43.0 hr	30.8 hr	23.0 hr	18.9 hr	16.1 hr
3 LPM	69.0 hr	47.7 hr	36.6 hr		

## **INSTRUCTIONS TO ENABLE DATA LOGGING AND DOWNLOAD LOGS**

F&J L-XPTR Series is capable of storing seven days of sampling data in the internal memory if data is logged every minute. To enable data logging follow the instructions below.

1. Set flow and calibrate the pump as mentioned in section 1.
2. In the main display, press Menu key (Down arrow) and scroll down to Log Sample Rate screen
3. By default log rate is Disabled. Press and Hold Set Key and Press UP arrow to enable log rate in the format of minutes . 1-255 mins.
4. Press ON key once to escape back to Main display or Down arrow to scroll through the menus and then to main display where sampling could be started by pressing RUN (UP arrow) and accumulate logs.

Requirements for Downloading Logged Data:

1. PC with Windows 10 or Windows 11 operating system and RS 232 port.
2. F&J PC Link Elite software package part no. 109101 (includes the PC link cable part no. 109048).

F&J PC Link Elite software package can be purchased from F&J.

F&J PC link cable 109048 needs to be connected to the RS232 port on the PC and the other end to the pump port . Pump needs to be turned on to make the connection.

If RS232 port is not present in the PC then a USB to RS232 adapter is required to make the connection. Check your lo-cal electronic store for this adapter and download the latest driver file to make this adapter work properly.

## EXAMPLE OF LOGGED DATA

PC Link Express Registered Version

File Help

Pump Communication Program Pump

Setup Pump Run Mode Logs

Serial Number: ELI50000 F&J L-5PTR

Number	R06	Log Type	Date/Time	Battery	Temperature	DP	Elapsed Mins	Flow Rate	Volume
1		Calibration	12/10/10 13:39:50	51 %	79 F	0.50 inH2O	0 mins	2000 ccl/min	0.00 L
2		Start Run	12/10/10 13:39:54	51 %	79 F	0.49 inH2O	0 mins	2000 ccl/min	0.00 L
3		Run Update	12/10/10 13:40:23	41 %	79 F	6.01 inH2O	0 mins	2000 ccl/min	0.93 L
4		Run Update	12/10/10 13:41:23	41 %	79 F	5.88 inH2O	1 mins	2000 ccl/min	2.93 L
5		Run Update	12/10/10 13:42:24	41 %	79 F	6.08 inH2O	2 mins	2000 ccl/min	4.93 L
6		Run Update	12/10/10 13:43:24	41 %	79 F	6.06 inH2O	3 mins	2000 ccl/min	6.93 L
7		Run Update	12/10/10 13:44:25	41 %	79 F	6.01 inH2O	4 mins	2000 ccl/min	8.93 L
8		Run Update	12/10/10 13:45:25	41 %	79 F	5.97 inH2O	5 mins	2000 ccl/min	10.93 L
9		Run Update	12/10/10 13:46:26	38 %	79 F	5.89 inH2O	6 mins	2000 ccl/min	12.93 L
10		Run Update	12/10/10 13:47:25	38 %	79 F	6.01 inH2O	7 mins	2000 ccl/min	14.93 L
11		Run Update	12/10/10 13:48:26	38 %	79 F	5.95 inH2O	8 mins	2000 ccl/min	16.93 L
12		Run Update	12/10/10 13:49:26	38 %	79 F	6.15 inH2O	9 mins	2000 ccl/min	18.93 L
13		Run Update	12/10/10 13:50:27	38 %	79 F	6.05 inH2O	10 mins	2000 ccl/min	20.93 L
14		Run Update	12/10/10 13:51:27	38 %	79 F	5.94 inH2O	11 mins	2000 ccl/min	22.93 L
15		Run Update	12/10/10 13:52:28	38 %	79 F	5.96 inH2O	12 mins	2000 ccl/min	24.93 L
16		User Stop	12/10/10 13:52:52	38 %	79 F	6.06 inH2O	12 mins	2000 ccl/min	25.76 L

Read Logs From Pump

Reading logs

Total Logs Saved are: 16

Save Logs Erase Logs In Pump Clear PC Screen

All logs are saved in English unit of Measurement